disassembly & recycling instructions task chair: upholstered back & seat



Affirm Cushioned Back applicable chair series Budget Contract (aka BC) D CE Classic **Classic Professional Discovery Back** Ginny Maxwell IU PT Paramount HD (formerly IUHD) PT Paramount IU (formerly IU) PT Paramount (formerly PT, 7xxx) PAC (formerly PA, PC, CLS) WS Series recommended tools Safety Glasses Work Gloves Flat Head Screw Driver Phillips Screw Driver Socket Wrench Set Allen Wrench Set Hammer (Sledge preferred) Pipe Wrench (24 inch preferred) Utility Knife Steel Putty Knife Magnet G Base Plastic or Aluminum Α recyclable material **B** Back Shell Plastic **C** Seat Board Plastic D Back Board Plastic Steel or Aluminum E Mechanism F Cylinder Steel Steel **G** Upright Bar Steel н Hardware

- 1 Start by laying the chair on its back.
- 2 Pull the casters off the base. Use a flat head screw driver if needed to pry them loose.
- 3 Separate the base (\mathbf{A}) from the cylinder (\mathbf{F}) by striking the bottom of the cylinder housing with a hammer.
- 4 For stool models, remove the footring from the cylinder by loosening the handwheel. If no handwheel is found, twist the entire footring.
- steps to disassemble 5 If the mechanism (**E**) has an aluminum body (a magnet will not attract to it), remove the cylinder from the mechanism. Use a pipe wrench to twist the piston inserted into the mechanism housing. If the mechanism is steel (a magnet will attract to it), the cylinder and mechanism can be recycled together.
 - 6 Remove the arms from the seat with a screw driver or socket wrench.
 - 7 Locate four bolts holding the mechanism to the seat, and remove them with a screw driver or socket wrench. If needed, slide the seat forward to access the screws.
 - 8 Pry apart the back shell (B) from the back with a flathead screw driver.
 - **9** With an allen wrench, remove the upright bar (**G**) from the back height adjust ratchet mechanism.
 - **10** Remove the back height adjust ratchet from the back board (**D**) with an allen wrench.
 - **11** Remove the fabric from the seat and back with a utility knife.
 - **12** Separate foam from the wood or plastic seat board (**C**) with putty knife.

disassembly & recycling inst guest/side chair

Affirm

Yes Ginny SG

Safety Glasses Work Gloves

A Leg Frame -

C Seat Board -

Back Board-

Back Frame

Mesh Frame

Hardware

D Arms

Glides-

G Back Shell

Bottom Cover —

Flat Head Screw Driver Phillips Screw Driver Socket Wrench Set Allen Wrench Set Utility Knife Steel Putty Knife

Affirm Cushioned Back Budget Contract (aka BC) PT Paramount (formerly PT, 7xxx)

applicable chair series

ecommended tools

recyclable material

В

Е

F

н

Т

J

cycling instructions	om seating
ck a BC) erly PT, 7xxx)	
rer	
- Steel - Plastic - Plastic - Plastic or Steel - Plastic - Plastic - Plastic - Plastic - Plastic - Plastic - Steel	

- Start by laying the chair on its back. steps to disassemble 1
 - Pull or unscrew the glides (\mathbf{E}) off the leg frame. Use a flat head or phillips head screw driver if needed. 2
 - Separate the bottom cover (\mathbf{B}) from the leg frame (\mathbf{A}) with a phillips head screw driver or allen wrench. 3
 - 4 Locate any screws holding the arms (D) to the leg frame or seat shell, remove the screws and pull off arms.
 - Remove the leg frame from the seat board (\mathbf{C}) with a screw driver and allen wrench. 5
 - Remove the fabric from the seat with a utility knife. 6

- Separate foam from the seat board with putty knife. 7
- For upholstered backs, remove the back shell (G) from the back board (F) using a phillips screw driver to pry them apart. 8
- **9** For mesh backs, separate the (\mathbf{H}) back frame from the (\mathbf{I}) mesh frame with a screw driver.